

MAKE: LANDROVER **TYPE:**

MODEL: Series II, IIA, III **YEAR:** 1958 – 1984

DETAIL: L.W.B. Pickup & Station Wagon, Santana 109
S.W.B. Santana 88

LAND-51



FRONT		TYPE	QTY	PART NUMBER
<p>LEAF SPRING Type 'A'</p> <p>9 Leaves Raised Height (40mm Lift)</p>		A	1	LAND-9L-F RH
		A	1	LAND-9L-F LH
<p>SHACKLE BUSH KIT Rubber Polyurethane Metal</p> <p>'A' Type 'B' 'C'</p> <p>S.W.B. Series II, IIA, III L.W.B. Series II, IIA</p> <p>Kit Contains: 4 x SPF2154 2 x SPF212</p>		B	1	PB51-1029K
<p>1973 on, Series III, L.W.B. Only</p> <p>Kit Contains: 4 x SPF2154 2 x SPF2155</p>		B	1	PB51-1081K
<p>U-BOLT KIT</p> <p>Type 'A' 'B' 'D'</p> <p>Series II, IIA Right Hand Side Kit Contains: 1 x UB51-601-1 1 x UB51-901</p> <p>Left Hand Side Kit Contains: 2 x UB51-601-1</p> <p>Series III Right Hand Side Kit Contains: 2 x UB51-903</p> <p>Left Hand Side Kit Contains: 1 x UB51-902 1 x UB51-903</p>		A	1	UB51-901K
		D	1	UB51-901K
		A	1	UB51-601-1K
		D	1	UB51-903K
		A	1	UB51-902K
<p>SHOCK ABSORBER</p> <p>Heavy Duty Gas</p> <p>Type 'A' 'B' 'C'</p>		A	2	GS51-090
<p>STEERING DAMPER</p> <p>Type 'A'</p> <p>Heavy Duty (Big Body) Complete with Fittings</p>		A	1	SD51-811

REAR		TYPE	QTY	PART NUMBER
<p>LEAF SPRING Type 'A'</p>				
<p>Suits S.W.B.</p> <p>11 Leaves Raised Height (45mm Lift)</p> <p>Suits L.W.B.</p> <p>8 Leaves Raised Height (45mm Lift)</p>		A	1	LAND-SWB-R RH
		A	1	LAND-SWB-R LH
<p>SHACKLE BUSH KIT Rubber Polyurethane Metal</p> <p>'A' Type 'B' 'C'</p> <p>Kit Contains: 6 x SPF2154</p>		B	1	PB61-1030K
<p>U-BOLT KIT</p> <p>Type 'A' 'B' 'C'</p> <p>Series II, IIA Kit Contains: 2 x UB51-601-1</p> <p>Series III Kit Contains: 2 x UB51-904</p>		A	2	UB51-601-1K
		A	2	UB51-904K
<p>SHOCK ABSORBER</p> <p>Type 'A' 'B' 'C'</p> <p>Suits S.W.B. (L.W.B. Pre 1958) Heavy Duty Gas</p> <p>Suits L.W.B. (1958 on) Heavy Duty Gas</p>		A	2	GS51-015C
		C	2	GS51-117

MAKE: LANDROVER **TYPE:** Range Rover

MODEL: **YEAR:** 1971 – 1998

DETAIL: Coil Spring Suspension
(Not with Air Suspension)

LAND-52



FRONT		TYPE	QTY	PART NUMBER
COIL SPRING Type 'C' 				
	Linear Rate Standard Height (20mm Lift)		2	C51-016 (Pair)
	Linear Rate Raised Height (45mm Lift)		2	C51-014 (Pair)
	Linear Rate Raised Height (40mm Lift) Diesel Engine Up to 50Kg Accessories		2	C51-018 (Pair)
SHOCK ABSORBER 				
	Heavy Duty Gas	D	2	GS51-116
STEERING DAMPER Type 'A' 				
	Heavy Duty (Big Body) Complete with Fittings	A	1	SD51-811
UNDER BODY BUSH KIT 				
NOTE: See Rear Under Body Bush Kit				
CASTOR KIT Front Leading Arm Castor Kit (±2°) Kit Contains: 4 x Eccentric Polyurethane Bushes Pre 1986 (Suit 38mm wide Leading Arm) - 1 PB51-501K After 1986 (Suit 44mm wide Leading Arm) - 1 PB51-502K Raising vehicle will affect castor angle. A wheel alignment is recommended to determine if a castor kit is required. Note: Do Not fit to Automatic Models as Vibration may occur				

REAR		TYPE	QTY	PART NUMBER
COIL SPRING Type 'C' 				
	Linear Rate Standard Height (20mm Lift)		2	C51-017 (Pair)
	Linear Rate Raised Height (45mm Lift)		2	C51-015 (Pair)
	Linear Rate Raised Height (45mm Lift) 150Kg to GVM		2	C51-022 (Pair)
SHOCK ABSORBER 				
	Heavy Duty Gas	C	2	GS51-117
UNDER BODY BUSH KIT 				
NOTE: Kit Includes Front & Rear Under Body Bushes Non EFI, Pre 01/1986 2 x Front Panhard Rod Bush 4 x Front Radius Arm to Diff Bush 4 x Front Radius Arm to Chassis Bush 2 x Rear Upper Arm to Chassis Bush 2 x Rear Lower Arm to Diff Bush 4 x Rear Lower Arm to Chassis Bush - 1 PB51-1242K With EFI, 02/1986 on 2 x Front Panhard Rod Bush 4 x Front Radius Arm to Diff Bush 4 x Front Radius Arm to Chassis Bush 2 x Rear Upper Arm to Chassis Bush 2 x Rear Lower Arm to Diff Bush 4 x Rear Lower Arm to Chassis Bush - 1 PB51-1243K				

MAKE: LANDROVER **TYPE:** Discovery

MODEL: Series I, II **YEAR:** 1991 – 03/1999

DETAIL:

LAND-55



FRONT		TYPE	QTY	PART NUMBER
COIL SPRING Type 'C' 				
	Linear Rate Standard Height (20mm Lift)		2	C51-016 (Pair)
	Linear Rate Raised Height (45mm Lift)		2	C51-014 (Pair)
	Linear Rate Raised Height (40mm Lift) Diesel Engine Up to 50Kg Accessories		2	C51-018 (Pair)
SHOCK ABSORBER 				
	Heavy Duty Gas Type 'A' 'B' 'D'	D	2	GS51-116
STEERING DAMPER 				
	Type 'A' Heavy Duty (Big Body) Complete with Fittings	A	1	SD51-811
UNDER BODY BUSH KIT 				
Polyurethane Bush				
NOTE: See Rear Under Body Bush Kit				
CASTOR KIT Front Leading Arm Castor Kit (±2°) Kit Contains: 4 x Eccentric Polyurethane Bushes (Suit 44mm wide Leading Arm)				
		-	1	PB51-502K
Raising vehicle will affect castor angle. A wheel alignment is recommended to determine if a castor kit is required. Note: Do Not fit to Automatic Models as Vibration may occur				

REAR		TYPE	QTY	PART NUMBER
COIL SPRING Type 'C' 				
	Variable Rate Standard Height (20mm Lift)		2	C51-025V (Pair)
	Linear Rate Raised Height (45mm Lift)		2	C51-015 (Pair)
	Variable Rate Raised Height (45mm Lift) Recommended		2	C51-023V (Pair)
	Variable Rate Raised Height (50mm Lift) Extra Heavy Duty 220Kg to GVM		2	C51-027V (Pair)
SHOCK ABSORBER 				
	Heavy Duty Gas Type 'A' 'B' 'C'	C	2	GS51-117
UNDER BODY BUSH KIT 				
Polyurethane Bush				
NOTE: Kit Includes Front & Rear Under Body Bushes 2 x Front Panhard Rod Bush 4 x Front Radius Arm to Diff Bush 4 x Front Radius Arm to Chassis Bush 2 x Rear Upper Arm to Chassis Bush 2 x Rear Lower Arm to Diff Bush 4 x Rear Lower Arm to Chassis Bush				
		-	1	PB51-1243K

MAKE: LANDROVER

TYPE: Discovery II

MODEL:

YEAR: 03/1999 – 2005

DETAIL: TD5



LAND-58

FRONT		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p> <p>Linear Rate Standard Height (20mm Lift)</p> <p>Linear Rate Raised Height (45mm Lift) Up to 40Kg Accessories Recommended</p> <p>Linear Rate Extra Heavy Duty Raised Height (45mm Lift) 40-100Kg Accessories</p>			2	C51-032 (Pair)
			2	C51-042 (Pair)
			2	C51-052 (Pair)
<p>SHOCK ABSORBER</p> <p>Type 'A' 'B' 'C'</p> <p>Heavy Duty Gas</p>		A	2	GS51-118
<p>STEERING DAMPER</p> <p>Type 'A'</p> <p>Heavy Duty (Big Body) Complete with Fittings</p>		A	1	SD51-802

REAR		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p> <p>Variable Rate Standard Height (20mm Lift)</p> <p>Linear Rate Raised Height (45mm Lift)</p> <p>Variable Rate Raised Height (45mm Lift) Recommended</p> <p>Variable Rate Raised Height (50mm Lift) 200Kg to GVM</p>			2	C51-025V (Pair)
			2	C51-015 (Pair)
			2	C51-023V (Pair)
			2	C51-027V (Pair)
<p>SHOCK ABSORBER</p> <p>Type 'A' 'B' 'C'</p> <p>Heavy Duty Gas</p>		A	2	GS51-119

MAKE: LANDROVER **TYPE:** Defender

MODEL: 90 Series **YEAR:** 1984 on

DETAIL: S.W.B.



LAND-54

FRONT		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p>				
Petrol	Linear Rate Raised Height (40mm Lift)		2	C51-014 (Pair)
	Linear Rate Raised Height (45mm Lift) 50-80Kg Accessories		2	C51-018 (Pair)
Diesel	Linear Rate Raised Height (45mm Lift) 80Kg Accessories		2	C51-018 (Pair)
<p>SHOCK ABSORBER</p>				
	Heavy Duty Gas	D	2	GS51-116
<p>STEERING DAMPER Type 'A' Heavy Duty (Big Body) Complete with Fittings</p>		A	1	SD51-832
<p>UNDER BODY BUSH KIT Polyurethane Bush</p> <p>NOTE: See Rear Under Body Bush Kit</p>				
<p>CASTOR KIT Front Leading Arm Castor Kit (±2°)</p> <p>Kit Contains: 4 x Eccentric Polyurethane Bushes</p> <p>(Suit 38mm wide Leading Arm)</p> <p>Raising vehicle will affect castor angle. A wheel alignment is recommended to determine if a castor kit is required.</p>		-	1	PB51-501K

REAR		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p>				
	Linear Rate Raised Height (45mm Lift)		2	C51-015 (Pair)
	Linear Rate Raised Height (50mm Lift) 220Kg to GVM		2	C51-027V (Pair)
<p>SHOCK ABSORBER</p>				
	Heavy Duty Gas	C	2	GS51-117
<p>UNDER BODY BUSH KIT Polyurethane Bush</p>				
<p>NOTE: Kit Includes Front & Rear Under Body Bushes</p>				
<p>Chassis Number up to LA930455</p> <p>2 x Front Panhard Rod Bush 4 x Front Radius Arm to Diff Bush 4 x Front Radius Arm to Chassis Bush 2 x Rear Upper Arm to Chassis Bush 2 x Rear Lower Arm to Diff Bush 4 x Rear Lower Arm to Chassis Bush</p>				
		-	1	PB51-1244K
<p>Chassis Number LA930456 on</p> <p>2 x Front Panhard Rod Bush 4 x Front Radius Arm to Diff Bush 4 x Front Radius Arm to Chassis Bush 2 x Rear Upper Arm to Chassis Bush 2 x Rear Lower Arm to Diff Bush 4 x Rear Lower Arm to Chassis Bush</p>				
		-	1	PB51-1243K

MAKE: LANDROVER **TYPE:** Defender

MODEL: 110 Series **YEAR:** 1984 – 1992

DETAIL: Pickup, 110 County Wagon, Trayback

LAND-53



FRONT		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p> <p>Suits: 110 V8 Petrol & 2.5L Diesel Linear Rate Raised Height (40mm Lift)</p> <p>Linear Rate Raised Height (40mm Lift) 80-100Kg Accessories</p> <p>Suits: 110 Isuzu Diesel (Pickup) Linear Rate Raised Height (30mm Lift)</p> <p>Linear Rate Raised Height (40mm Lift) 80-100Kg Accessories</p>			2	C51-017 (Pair)
			2	C51-015 (Pair)
			2	C51-015 (Pair)
			2	C51-022 (Pair)
<p>SHOCK ABSORBER</p> <p>Heavy Duty Gas</p> <p>Type 'A' 'B' 'D'</p>		D	2	GS51-116
<p>STEERING DAMPER Type 'A'</p> <p>Heavy Duty (Big Body) Complete with Fittings</p>		A	1	SD51-832
<p>UNDER BODY BUSH KIT</p> <p>NOTE: Polyurethane Bush See Rear Under Body Bush Kit</p>				
<p>CASTOR KIT</p> <p>Front Leading Arm Castor Kit ($\pm 2^\circ$)</p> <p>Kit Contains: 4 x Eccentric Polyurethane Bushes</p> <p>Isuzu Diesel Engine (Suit 38mm wide Leading Arm) - 1 PB51-501K</p> <p>Petrol Only (Suit 38mm wide Leading Arm) - 1 PB51-501K (Suit 44mm wide Leading Arm) - 1 PB51-502K</p> <p>Raising vehicle will affect castor angle. A wheel alignment is recommended to determine if a castor kit is required.</p>				

REAR		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p> <p>Suits: 110 Wagon & Pickup Vehicle with Self Levelling Valve</p> <p>Linear Rate Raised Height</p> <p>Suits: 110 Wagon & Pickup Vehicle without Self Levelling Valve</p> <p>Linear Rate Raised Height (45mm Lift) Light Load to 250Kg to GVM</p> <p>Linear Rate Raised Height (45mm Lift) 350Kg to GVM</p>			2	C51-001 (Pair)
			2	C51-019 (Pair)
			2	C51-011 (Pair)
<p>SHOCK ABSORBER</p> <p>Heavy Duty Gas</p> <p>Type 'A' 'B' 'C'</p>		C	2	GS51-117
<p>UNDER BODY BUSH KIT</p> <p>NOTE: Kit Contains Front & Rear Under Body Bushes</p> <p>Chassis Number up to LA930434 2 x Front Panhard Rod Bush 4 x Front Radius Arm to Diff Bush 4 x Front Radius Arm to Chassis Bush 2 x Rear Upper Arm to Chassis Bush 2 x Rear Lower Arm to Diff Bush 4 x Rear Lower Arm to Chassis Bush</p> <p>Chassis Number LA930435 on 2 x Front Panhard Rod Bush 4 x Front Radius Arm to Diff Bush 4 x Front Radius Arm to Chassis Bush 2 x Rear Upper Arm to Chassis Bush 2 x Rear Lower Arm to Diff Bush 4 x Rear Lower Arm to Chassis Bush</p>			1	PB51-1244K
			1	PB51-1243K

MAKE: LANDROVER **TYPE:** Defender

MODEL: 110 & 130 Series **YEAR:** 1992 – 2001

DETAIL: L.W.B. 110" Wheel Base 300 TDi
130" Wheel Base Double Cab LAND-56



FRONT		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p>				
<p>Suits: 110 Series 130 Series</p> <p>Linear Rate Standard Height</p>			2	C51-020 (Pair)
<p>Suits: 110 Series 130 Series</p> <p>Linear Rate Raised Height (30mm Lift) Up to 50Kg Accessories</p>			2	C51-018 (Pair)
<p>Linear Rate Raised Height (45mm Lift) 80-120Kg Accessories</p>			2	C51-026 (Pair)
<p>SHOCK ABSORBER</p>				
<p>Heavy Duty Gas</p> <p>Type 'A' 'B' 'D'</p>		D	2	GS51-116
<p>STEERING DAMPER Type 'A'</p>				
<p>Heavy Duty (Big Body) Complete with Fittings</p>		A	1	SD51-832
<p>UNDER BODY BUSH KIT</p>				
<p>Polyurethane Bush</p>				
<p>NOTE: See Rear Under Body Bush Kit</p>				
<p>CASTOR KIT Front Leading Arm Castor Kit (±2°)</p>				
<p>Kit Contains: 4 x Eccentric Polyurethane Bushes</p>				
<p>110 Series (Suit 38mm wide Leading Arm)</p>		-	1	PB51-501K
<p>(Suit 44mm wide Leading Arm)</p>		-	1	PB51-502K
<p>130 Series (Suit 44mm wide Leading Arm)</p>		-	1	PB51-502K
<p>Raising vehicle will affect castor angle. A wheel alignment is recommended to determine if a castor kit is required.</p>				

REAR		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p>				
<p>Suits: 110 Series</p> <p>Linear Rate Standard Height</p>			2	C51-007 (Pair)
<p>Linear Rate Raised Height (45mm Lift) Light Load to 250Kg to GVM</p>			2	C51-019 (Pair)
<p>Linear Rate Raised Height (45mm Lift) Up to 350Kg to GVM</p>			2	C51-011 (Pair)
<p>Suits: 130 Series</p> <p>Linear Rate Raised Height (45mm Lift)</p>			2	C51-009 (Pair)
<p>Note: Replace Inner Coil Helper for Maximum Load Carrying Capacity</p>				
<p>SHOCK ABSORBER</p>				
<p>Heavy Duty Gas</p> <p>Type 'A' 'B' 'C'</p>		C	2	GS51-117
<p>UNDER BODY BUSH KIT</p>				
<p>Polyurethane Bush</p>				
<p>NOTE: Kit Includes Front & Rear Under Body Bushes</p>				
<p>From Chassis Number LA930435</p>				
<p>2 x Front Panhard Rod Bush 4 x Front Radius Arm to Diff Bush 4 x Front Radius Arm to Chassis Bush 2 x Rear Upper Arm to Chassis Bush 2 x Rear Lower Arm to Diff Bush 4 x Rear Lower Arm to Chassis Bush</p>		-	1	PB51-1243K

